

# ELECTRICAL SAFETY RECALL

**BSH Home Appliances Pty Ltd is issuing a recall on specified Bosch dishwashers sold in Australia through various retailers.**

## Which models are affected?

Bosch dishwashers with the following model numbers manufactured between 2000 and 2006 are affected:

SGI4335AU; SGI4345AU; SGI4347AU; SGI43A25AU; SGI43A45AU;  
SGI43A55AU; SGI4705AU; SGI4715AU; SGI53A55AU; SGS4332AU;  
SGS4352AU; SGS43A92AU; SGS43B22AU; SGS43B42AU;  
SGS4702AU; SGS4712AU; SGS5332AU; SGS53A52AU;  
SRI43A05AU; SRS5302AU.

## Where to find the model number on the machine?

The model identification numbers can be found on the top inside edge of the door panel as shown below.


## Product Issue

In some circumstances, the components in the dishwasher's control module may fail creating a fire hazard.


## Hazard: Risk of Fire.

## What should I do?

- Cease using the dishwasher immediately and switch it off at the Socket Outlet.
- Check the model number and contact the Bosch Repair Team between 9am and 5pm, Monday to Friday, on 1300 369 744 or visit [www.bosch-home.com.au/repair](http://www.bosch-home.com.au/repair) to arrange the free, in-home repair.



Model Number (E-Nr.)



**See [www.recalls.gov.au](http://www.recalls.gov.au) for  
Australian Product Recall Information**